



INSTALLATION MANUAL



BRPP Sidestand Shoe: KTM 390 Adventure

Welcome to the BigRock Performance Parts family!

Thank you for your purchase of the BigRock Performance Parts Sidestand Shoe. You are now a proud owner of a product that comes from our years of rally raid, supercross, motocross, enduro and trail riding experience. It has been designed and developed by BigRock in response to a specific need we felt wasn't met adequately. That's why you will find the same products on our own motorcycles that we use every day. We've put all of our collective motorcycling experience into developing this product so that you can fit it and forget it!

What's in the box?



- 1. Bottom plate x1
- 2. Top plate x1
- 3. Mounting bolt x3

Step 1

Place the bottom plate below the sidestand base.



Step 2

Place the top plate over the base plate with the groove aligned with the sidestand stem. Also pay attention to the mounting points on the top plate and bottom plate and make sure they are aligned.



Step 3

Insert the three mounting bolts into the mounting points and tighten them securely.



Feedback?

Good or bad, we'd love to hear it!
Reach us at performanceparts@bigrockdirtpark.com

THANK YOU!